



135 Matheson Blvd. East, Mississauga, ON L4Z 1R2
1-800-891-5811

SUGGESTED MAINTENANCE SCHEDULE FOR HYDROTHER COMMERCIAL HOT TUBS

DAILY

VISUALLY CHECK ALL FITTINGS, RAILINGS, SURROUNDING DECK AREA, ETC TO THAT THERE ARE NO HAZARDS
CHECK THAT ALL SIGNS ARE POSTED, THE EMERGENCY PHONE IS IN WORKING ORDER AND THAT THE FIRST AID KIT IS PROPERLY STOCKED
CHECK WATER LEVEL IS AT LEAST HALF WAY UP SKIMMER
(NOT NECESSARY IF EQUIPPED WITH AUTOMATIC WATER LEVELOR)
TEST AND RECORD BROMINE/CHLORINE, PH, AND ALKALINITY LEVEL OF WATER EVERY BEFORE OPENING HOT TUB AND EVERY TWO HOURS THEREAFTER. (ONLY NECESSARY ONCE A DAY IF EQUIPPED WITH CHEMICAL CONTROLLER)
DESIRED LEVELS ARE: CHLORINE OR BROMINE 3-5 PPM.
PH 7.4 -7.6
ALKALINITY 80 -120 PPM

WEEKLY

CLEAN PERIMETER SCUM OR TILE LINE WITH NON ABRASIVE APPROVED CLEANER
ADJUST AND CALIBRATE CHEMICAL CONTROLLERS

BI-WEEKLY

DRAIN, REFILL HOT TUB AND CLEAN ACRYLIC SURFACE WITH APPROVED NON-ABRASIVE CLEANER WHILE EMPTY. PLEASE NOTE THAT FOR INSTALLATIONS WITH EXTREME HEAVY USE DRAINING THE HOT TUB MORE OFTEN MAY BE NECESSARY...SEE BELOW FORMULA. IN THE EVENT THAT THE TUB WILL BE EMPTY AND AS A RESULT THE CHEMICAL CONTROLLER PROBES WILL NOT BE SUBMERSED IN WATER YOU SHOULD REMOVE THE PROBES AND TEMPORARILY PLACE THEM IN A CONTAINER OF WATER.

FORMULA FOR DETERMINING NEED TO DRAIN HOT TUB

$\frac{1}{3}$ GALLONAGE OF THE HOT TUB DIVIDED BY THE AVERAGE DAILY NUMBER OF USERS
EQUALS THE DAYS BETWEEN DRAININGS

REPLACE CARTRIDGE FILTER. PRESSURE SPRAY CLEAN DIRTY CARTRIDGE FILTER, SOAK OVERNIGHT IN CARTRIDGE CLEANER, RINSE CLEAN AND STORE FOR UNTIL OTHER CARTRIDGE REQUIRES CHANGING IN TWO WEEKS.

QUARTERLY

CHECK ALL JETS AND SUCTION FITTINGS. CLEAN WITH VINEGAR SOLUTION TO REMOVE SCALE.

YEARLY

PURCHASE NEW CARTRIDGES FOR FILTER
REPLACE PROBES ON CHEMICAL CONTROLLER